

Supplement:

- 1. The storage room is dry, dust-free, and moderately ventilated; avoid direct sunlight. It is recommended to use red or orange shades for windows in the storage place;
- 2. The storage temperature is 0-40°C. If it is transported at low temperature, it must be thawed at a room temperature of 20°C, and care must be taken during transportation and operation to prevent deformation or damage due to the hardening of the rubber;
- 3. Ozone equipment, fluorescent lamps or strong artificial power sources with high ultraviolet content, mercury vapor, high-voltage electrical appliances, electric motors, etc. should not be used in the storage room;
- 4. The storage of rubber gaskets should avoid their deformation as much as possible. The stored rubber gaskets should avoid heavy pressure, and should not be stretched or compressed; it is forbidden to hang the rubber gaskets with strings, iron wires, etc;
- 5. Conditionally use bags or boxes for storage and the packaging materials must not contain substances that have a degrading effect on rubber, so as to reduce air circulation and slow down aging;
- 6. Separately store gaskets of different materials.

www.hofmann-heatexchanger.com Hofmann (Beijing) Engineering Technology Co., Ltd.

Tel.: +86 10 8447 8229

Email: service@hfm-phe.com

Copyright @ 2019 Hofmann (Beijing) Engineering Technology Co., Ltd. All Rights Reserved









